

REUSE MANUAL

BONNE

10xxxxxx.1

Implementation

TABLE OF CONTENTS

TABLE OF CONTENTS	I
SECTION 1. INTRODUCTION	1
1.1 PURPOSE OF THE REUSE MANUAL	1
1.2 PURPOSE OF THE REUSABLE SOFTWARE COMPONENT	1
1.3 GENERAL INFORMATION.....	2
1.3.1 POINT OF CONTACT	2
1.3.2 CERTIFICATION LEVEL	2
1.3.3 LEGAL RESTRICTIONS.....	2
SECTION 2. INSTALLATION	3
2.1 PARTIAL REUSE	3
2.2 MODIFICATIONS.....	3
SECTION 3. ENVIRONMENT	4
3.1 HARDWARE.....	4
3.1.1 DEVELOPMENT	4
3.1.2 TARGET	4
3.2 SOFTWARE	4
3.2.1 OPERATING SYSTEM	4
3.2.2 COMPILERS.....	4
3.3 ASSUMPTIONS AND PERFORMANCE LIMITATIONS.....	5
SECTION 4. GLOBAL RSC ENVIRONMENT	6
4.1 TYPES.....	6
4.2 CONSTANTS	6
4.3 VARIABLES.....	6
4.4 INCLUDE FILES	7
4.5 DEPENDENCIES	7
SECTION 5. FUNCTIONS.....	8
5.1 SET_BONNE_PARAMETERS.....	8
5.2 GET_BONNE_PARAMETERS.....	10

5.3	CONVERT_GEODETTIC_TO_BONNE	11
5.4	CONVERT_BONNE_TO_GEODETTIC	13
APPENDIX A STRUCTURE/DEPENDENCY DIAGRAMS.....		15
APPENDIX B DEFINITIONS/GLOSSARY		16
APPENDIX C REFERENCES		18

SECTION 1. INTRODUCTION

1.1 PURPOSE OF THE REUSE MANUAL

This document describes the characteristics of the BONNE reusable software component and provides instructions on its installation and operation. The manual is a self-contained reference for the software engineer intending to incorporate the component in another software system. This manual was written with the assumption that the user has a basic working knowledge of C and is familiar with fundamental C concepts and terminology.

1.2 PURPOSE OF THE REUSABLE SOFTWARE COMPONENT

The purpose of BONNE is to provide a reusable software component which supports the following coordinate conversions :

- Geodetic coordinates (latitude and longitude in radians) to Bonne projection coordinates (easting and northing in meters), and
- Bonne projection coordinates (easting and northing in meters) to Geodetic coordinates (latitude and longitude in radians).

A particular ellipsoid is specified in terms of the following parameters:

- Semi-Major Axis (a) – Radius (in meters) at the equator.
- Semi-Minor Axis (b) – Radius (in meters) at a pole.

A particular variation of the Bonne projection is specified in terms of the following parameters:

- Central Meridian – Longitude (in radians) at the horizontal center of the projection,
- Origin Latitude – Latitude (in radians) at which the scale factor of the projection is 1.0,
- False Easting – A coordinate value (in meters) assigned to the central meridian of the projection to avoid the inconvenience of using negative coordinates,
- False Northing – A coordinate value (in meters) assigned to the origin latitude of the projection to avoid the inconvenience of using negative coordinates.

1.3 GENERAL INFORMATION

1.3.1 POINT OF CONTACT

U.S. Army Topographic Engineering Center (USATEC)

Geospatial Information Division

ATTN: CETEC-GD-A (Dan Specht)

7701 Telegraph Road

Alexandria, VA 22315-3864

Dan Specht (703) 428 - 6761 Project Manager

1.3.2 CERTIFICATION LEVEL

This RSC has been certified at level 4. A level 4 component satisfies the criteria for reliability, testing, and documentation for the Army Reuse Center (ARC). The component comes with test materials and a Reuse Manual that aids in integrating the component into a software system.

1.3.3 LEGAL RESTRICTIONS

This Reusable Software Component (RSC) contains data with Unlimited Government Rights.

SECTION 2. INSTALLATION

The following is a list of the files that make up the BONNE component:

Source Code Files:

`bonne.c`

Header Files :

`bonne.h`

Data Files :

`none`

The compilation instructions for the BONNE component are as follows:

DOS Makefile (Uses Microsoft C):

```
cl /nologo /W3 /FR /G2 /DNDEBUG /Gs /Ox /AM /D_DOS /c bonne.c
```

UNIX Makefile (Uses gcc compiler):

```
cc -g -O -ansi -Wall -c bonne.c
```

The compilation order of the BONNE component relative to other components is unconstrained.

2.1 PARTIAL REUSE

The BONNE component does not allow for partial reuse.

2.2 MODIFICATIONS

The BONNE component does not permit modifications.

SECTION 3. ENVIRONMENT

This section provides details on the environment under which BONNE was developed, tested, and executed.

3.1 HARDWARE

3.1.1 DEVELOPMENT

The following is a list of hardware configurations under which BONNE was developed and tested.

- SUN SparcStation 20
- IBM compatible Pentium PC

3.1.2 TARGET

The following is a list of hardware configurations under which BONNE was executed.

- SUN SparcStation 20
- IBM compatible Pentium PC

3.2 SOFTWARE

3.2.1 OPERATING SYSTEM

The following is a list of operating systems under which BONNE was executed and tested.

- Solaris 2.5
- Windows 95

3.2.2 COMPILERS

The following is a list of compilers on which BONNE was compiled successfully.

- GCC version 2.8.1

- Microsoft Visual C++ version 6

3.3 ASSUMPTIONS AND PERFORMANCE LIMITATIONS

There are no hardware or environment constraints. There are no limitations.

This RSC is written in ANSI C.

SECTION 4. GLOBAL RSC ENVIRONMENT

4.1 TYPES

Not applicable.

4.2 CONSTANTS

The following is a list of significant visible constants declared globally in BONNE with their descriptions.

BONN_NO_ERROR	: No errors occurred in function
BONN_LAT_ERROR	: Latitude outside of valid range (-87 to 87 degrees)
BONN_LON_ERROR	: Longitude outside of valid range (-180 to 360 degrees)
BONN_EASTING_ERROR	: Easting outside of valid range (False_Easting +/- ~20,500,000 m, depending on ellipsoid parameters and Origin_Latitude)
BONN_NORTHING_ERROR	: Northing outside of valid range (False_Northing +/- ~23,500,000 m, depending on ellipsoid parameters and Origin_Latitude)
BONN_ORIGIN_LAT_ERROR	: Origin latitude outside of valid range (-87 to 87 degrees)
BONN_CENT_MER_ERROR	: Central meridian outside of valid range (-180 to 360 degrees)
BONN_A_ERROR	: Semi-major axis less than or equal to zero
BONN_B_ERROR	: Semi-minor axis less than or equal to zero
BONN_A_LESS_B_ERROR	: Semi-major axis less than semi-minor axis

4.3 VARIABLES

The following is a list of significant global variables declared in BONNE with their descriptions.

```
Ellipsoid Parameters:
static double Bonn_a      : Semi-major axis of ellipsoid in meters
static double Bonn_b      : Semi-minor axis of ellipsoid in meters

Projection Parameters:
static double Bonn_Origin_Lat  : Latitude of origin in radians
static double Bonn_Origin_Long : Longitude of origin in radians
static double Bonn_False_Easting : False easting in meters
static double Bonn_False_Northing : False northing in meters

Maximum easting and northing values (for default ellipsoid and projection):
static double Bonn_Delta_Easting
static double Bonn_Delta_Northing
```

4.4 INCLUDE FILES

<code>math.h</code>	: Standard C math library
<code>bonne.h</code>	: Error codes and prototype error checking

4.5 DEPENDENCIES

None, other than the standard ANSI C math library.

SECTION 5. FUNCTIONS

5.1 SET_BONNE_PARAMETERS

5.1.1 DESCRIPTION

This function sets the ellipsoid and Bonne projection parameters to the specified values.

5.1.2 INTERFACES AND EXAMPLES

The following is a list of the formal arguments required to use this function.

```
long Set_Bonne_Parameters (double a,  
                           double b,  
                           double Origin_Latitude,  
                           double Central_Meridian,  
                           double False_Easting,  
                           double False_Northing);
```

a	Semi-major axis of ellipsoid in meters (input),
b	Semi-minor axis of ellipsoid in meters (input),
Origin_Latitude	Latitude in radians at which the point scale factor is 1.0 (input),
Central_Meridian	Longitude in radians at the center of the projection (input),
False_Easting	Coordinate value in meters assigned to the central meridian (input),
False_Northing	Coordinate value in meters assigned to the origin latitude (input),

Example:

```
status = Set_Bonne_Parameters (a, b, Origin_Latitude, Central_Meridian,  
                               False_Easting, False_Northing)
```

Inputs:

a	6378137.0
b	6356752.3142
Origin_Latitude	0.0
Central_Meridian	0.0

False_Easting 0.0

False_Northing 0.0

Outputs:

None

5.1.3 DECLARATIONS

5.1.3.1 TYPES

Not applicable.

5.1.3.2 CONSTANTS

Not applicable.

5.1.3.3 VARIABLES

Not applicable.

5.1.4 DEPENDENCIES

Convert_Bonne_To_Geodetic – used to determine maximum valid easting and northing values for current ellipsoid and Bonne projection parameters.

5.1.5 ERROR HANDLING

This function returns the following status codes:

BONN_NO_ERROR	: No errors occurred in function
BONN_ORIGIN_LAT_ERROR	: Origin latitude outside of valid range (-87 to 87 degrees)
BONN_CENT_MER_ERROR	: Central meridian outside of valid range (-180 to 360 degrees)
BONN_A_ERROR	: Semi-major axis less than or equal to zero
BONN_B_ERROR	: Semi-minor axis less than or equal to zero
BONN_A_LESS_B_ERROR	: Semi-major axis less than semi-minor axis

5.2 GET_BONNE_PARAMETERS

5.2.1 DESCRIPTION

This function returns the current values of the ellipsoid parameters, and Bonne projection parameters.

5.2.2 INTERFACES AND EXAMPLES

The following is a list of the formal arguments required to use this function.

```
void Get_Bonne_Parameters (double *a,  
                           double *b,  
                           double *Origin_Latitude,  
                           double *Central_Meridian,  
                           double *False_Easting,  
                           double *False_Northing);
```

a	Semi-major axis of ellipsoid in meters (output),
b	Semi-minor axis of ellipsoid in meters (output),
Origin_Latitude	Latitude in radians at which the point scale factor is 1.0 (output),
Central_Meridian	Longitude in radians at the center of the projection (output),
False_Easting	Coordinate value in meters assigned to the central meridian (output),
False_Northing	Coordinate value in meters assigned to the origin latitude (output),

5.2.3 DECLARATIONS

5.2.3.1 TYPES

Not applicable.

5.2.3.2 CONSTANTS

Not applicable.

5.2.3.3 VARIABLES

Not applicable.

5.2.4 DEPENDENCIES

None.

5.2.5 ERROR HANDLING

No errors are reported by this function.

5.3 CONVERT_GEODETTIC_TO_BONNE

5.3.1 DESCRIPTION

This function converts Geodetic coordinates (latitude and longitude in radians) to Bonne projection coordinates (easting and northing in meters), using the current ellipsoid and Bonne projection parameters.

5.3.2 INTERFACES AND EXAMPLES

The following is a list of the formal arguments required to use this function.

```
long Convert_Geodetic_To_Bonne (double Latitude,  
                                double Longitude,  
                                double *Easting,  
                                double *Northing);
```

Latitude	Latitude in radians (input),
Longitude	Longitude in radians (input),
Easting	Easting (X) in meters (output),
Northing	Northing (Y) in meters (output).

Example:

```
status = Convert_Geodetic_To_Bonne (Latitude, Longitude, Easting, Northing)
```

Inputs:

Latitude:	-35.0
-----------	-------

Longitude: 75.0

Outputs:

Easting: -1910804.77

Northing: -1463929.01

5.3.3 DECLARATIONS

5.3.3.1 TYPES

Not applicable.

5.3.3.2 CONSTANTS

Not applicable.

5.3.3.3 VARIABLES

Not applicable.

5.3.4 DEPENDENCIES

None.

5.3.5 ERROR HANDLING

This function returns the following status codes:

BONN_NO_ERROR	: No errors occurred in function
BONN_LAT_ERROR	: Latitude outside of valid range (-87 to 87 degrees)
BONN_LON_ERROR	: Longitude outside of valid range (-180 to 360 degrees)

5.4 CONVERT_BONNE_TO_GEODETTIC

5.4.1 DESCRIPTION

This function converts Bonne projection coordinates (easting and northing in meters) to Geodetic coordinates (latitude and longitude in radians), using the current ellipsoid and Bonne projection parameters.

5.4.2 INTERFACES AND EXAMPLES

The following is a list of the formal arguments required to use this function.

```
long Convert_Bonne_To_Geodetic (double Easting,  
                                double Northing,  
                                double *Latitude,  
                                double *Longitude);
```

Easting	Easting (X) in meters (input),
Northing	Northing (Y) in meters (input),
Latitude	Latitude in radians (output),
Longitude	Longitude in radians (output).

Example:

```
status = Convert_Bonne_To_Geodetic (Easting, Northing, Latitude, Longitude)
```

Inputs:

Easting:	-1910804.77
Northing:	-1463929.01

Outputs:

Latitude:	-35.0
Longitude:	75.0

5.4.3 DECLARATIONS

5.4.3.1 TYPES

Not applicable.

5.4.3.2 CONSTANTS

Not applicable.

5.4.3.3 VARIABLES

Not applicable.

5.4.4 DEPENDENCIES

None.

5.4.5 ERROR HANDLING

This function returns the following status codes:

BONN_NO_ERROR	: No errors occurred in function
BONN_EASTING_ERROR	: Easting outside of valid range (False_Easting +/- ~20,500,000 m, depending on ellipsoid parameters and Origin_Latitude)
BONN_NORTHING_ERROR	: Northing outside of valid range (False_Northing +/- ~23,500,000 m, depending on ellipsoid parameters and Origin_Latitude)

APPENDIX A STRUCTURE/DEPENDENCY DIAGRAMS

This component consists of a single compilation unit and depends only on the ANSI C standard math library.

APPENDIX B DEFINITIONS/GLOSSARY

Bonne Projection – A pseudoconical, equal area projection for which the scale factor is one along the central meridian and along all parallels. Poles appear as points.

Central Meridian – Longitude at the horizontal center of a projection.

Coordinate – Linear or angular quantities that designate the position that a point occupies in a given reference frame or system. Also used as a general term to designate the particular kind of reference frame or system, such as Cartesian or spherical coordinates.

Ellipsoid – The surface generated by an ellipse rotating about one of its axes.

False Easting – A coordinate value (in meters) assigned to the central meridian of the projection to avoid the inconvenience of using negative coordinates.

False Northing – A coordinate value (in meters) assigned to the origin latitude of the projection to avoid the inconvenience of using negative coordinates.

Geodetic Coordinates – The quantities of latitude and longitude that define the position of a point on the surface of the earth with respect to the reference ellipsoid. Also, imprecisely called geographic coordinates.

Geodetic Latitude – The angle between the plane of the equator and the normal to the ellipsoid through the computation point. Geodetic latitude is positive north of the equator and negative south of the equator.

Geodetic Longitude – The angle between the plane of a meridian and the plane of the prime meridian. A longitude can be measured from the angle formed between the local and prime meridians at the pole of rotation of the reference ellipsoid, or by the arc along the equator intercepted by these meridians.

Map Projection – A function relating coordinates of points on a curved surface (usually an ellipsoid or sphere) to coordinates of points on a plane. A map projection may be established by analytical computation or, less commonly, may be constructed geometrically.

Map Scale – The ratio between a distance on a map and the corresponding actual distance on the earth's surface.

Meridian – A north-south reference line, particularly a great circle through the geographical poles of the earth, from which longitudes and azimuths are determined; or the intersection of a plane forming a great circle that contains both geographic poles of the earth, and the ellipsoid.

Origin Latitude – Latitude at which the scale factor of the projection is 1.0.

Parallel – A line on the earth, or a representation thereof, that represents the same latitude at every point.

Scale Factor (Projection) – A multiplier for reducing a distance in a map projection to the actual distance on the chosen reference ellipsoid.

APPENDIX C REFERENCES

(1) Topographic Engineering Center, TEC-SR-7,.**Handbook for transformation of DATUMS, PROJECTIONS, GRIDS, AND COMMON COORDINATE SYSTEMS**, January 1996.

(2) Snyder, J. P., **Geological Survey Professional Paper 1395 Map Projections - A Working Manual**, 1987.