

To configure your ZyAIR, use one of the following applications:

In Windows XP:

- ZyXEL ZyAIR Utility
- Zero Configuration
- Funk Odyssey Client

In Windows 98 SE/Me/2000

- ZyXEL ZyAIR Utility
- Funk Odyssey Client

Note:

It is recommended you use the ZyAIR Utility to configure your ZyAIR.

The bundled Funk wireless LAN utility only works for your ZyAIR. Do NOT use the Funk utility to configure non-ZyXEL WLAN adapters.

Known Issue:

After you plug and unplug a non-ZyXEL WLAN adapter, you cannot use the Funk utility to configure your ZyAIR again. To solve this problem, do one of the following

- Reboot your computer.
- Restart the utility.