

## ORP Monitor Quick Reference

| Command | Parameters                | Description                       |
|---------|---------------------------|-----------------------------------|
| help    |                           | shows help                        |
| dm      | <start addr> [<end addr>] | display 32-bit memory location(s) |
| pm      | <addr> [<stop_addr>]      |                                   |